

Архангельск (8182)63-90-72	Калининград (4012)72-03-81	Нижний Новгород(831)429-08-12	Смоленск (4812)29-41-54
Астана +7(7172)727-132	Калуга (4842)92-23-67	Новокузнецк (3843)20-46-81	Сочи (862)225-72-31
Белгород (4722)40-23-64	Кемерово (3842)65-04-62	Новосибирск (383)227-86-73	Ставрополь (8652)20-65-13
Брянск (4832)59-03-52	Киров (8332)68-02-04	Орел (4862)44-53-42	Тверь (4822)63-31-35
Владивосток (423)249-28-31	Краснодар (861)203-40-90	Оренбург (3532)37-68-04	Томск (3822)98-41-53
Волгоград (844)278-03-48	Красноярск (391)204-63-61	Пенза (8412)22-31-16	Тула (4872)74-02-29
Вологда (8172)26-41-59	Курск (4712)77-13-04	Пермь (342)205-81-47	Тюмень (3452)66-21-18
Воронеж (473)204-51-73	Липецк (4742)52-20-81	Ростов-на-Дону (863)308-18-15	Ульяновск (8422)24-23-59
Екатеринбург (343)384-55-89	Магнитогорск (3519)55-03-13	Рязань (4912)46-61-64	Уфа (347)229-48-12
Иваново (4932)77-34-06	Москва (495)268-04-70	Самара (846)206-03-16	Челябинск (351)202-03-61
Ижевск (3412)26-03-58	Мурманск (8152)59-64-93	Санкт-Петербург (812)309-46-40	Череповец (8202)49-02-64
Казань (843)206-01-48	Набережные Челны(8552)205341	Саратов (845)249-38-78	Ярославль (4852)69-52-93

Единый адрес для всех регионов mtt@nt-rt.ru || <http://mttd.nt-rt.ru>

Дополнительные дисплеи

Бывает, что следить за показаниями дисплея весов неудобно. Например, работать с высокими контейнерами проще, если дисплей расположен на уровне глаз.

Для решения этой проблемы мы советуем использовать выносной дисплей, который можно установить в любом удобном месте или прикрепить с помощью штатива прямо к весам.

AD-RS-J7



Auxiliary display AD-RS-J7, RS232 large LCD backlit display powered by the balance (RS232 interface) Dimensions (W/D/H): 160/40/70 mm.
JP, JS

AD-RS-M7



Auxiliary display AD-RS-M7, RS232 large LCD backlit display powered by the balance (RS232 interface). Dimensions (W/D/H): 160/40/70 mm.
MS, MS-S, MS-L, ML, PHS, PHL

BT-BLD



Auxiliary LCD display with backlighting, wireless connection up to 10 m, for table or wall mounting, Dimensions (W/D/H): 182/60/168 mm.
XP, XS, XA Precision Balances with Bluetooth BT or BTS interface

RS-AD-L7, PS2



Auxiliary display RS-AD-L7, PS2 LCD display with backlight.
PL-S

RS-AD-L7, RS232



Auxiliary display RS-AD-L7, RS232 LCD display with backlight.
PL-S, PL-L

RS/LC-BLD



Auxiliary LCD display with backlighting, for table mounting, incl. a two meters RS232C connection cable. Dimensions (W/D/H) 182/60/168 mm.
all balances with RS232C or LocalCAN interface

RS/LC-BLDS



Auxiliary LCD display with backlighting, for table or balance mounting incl. a two meters RS232C connection cable. Dimensions (W/D/H): 182/60/480 mm.
XP, XS or XA Precision Balances with RS232C or LocalCAN interface

Stand for terminal

Stand for placement of the terminal 30 cm above the small or medium weighing pan.
XP, XS, XA Precision Balances (S or M Platforms)

Stand for terminal



Stand for placement of the terminal 30 cm above the large weighing pan.
XP, XS, XA Precision Balances (L Platforms)

Stand for terminal or printer



Stand for placement of the terminal or printer above the analytical balance.
XP, XS, XA Analytical Balances

Terminal extension cable



Terminal extension cable, 4.5 m
XP, XS, XA

Terminal wall mounting



Wall fixture for terminal wall mounting, incl. terminal extension cable, 1.8 m.
XP, XS, XA

Архангельск (8182)63-90-72	Калининград (4012)72-03-81	Нижний Новгород(831)429-08-12	Смоленск (4812)29-41-54
Астана +7(7172)727-132	Калуга (4842)92-23-67	Новокузнецк (3843)20-46-81	Сочи (862)225-72-31
Белгород (4722)40-23-64	Кемерово (3842)65-04-62	Новосибирск (383)227-86-73	Ставрополь (8652)20-65-13
Брянск (4832)59-03-52	Киров (8332)68-02-04	Орел (4862)44-53-42	Тверь (4822)63-31-35
Владивосток (423)249-28-31	Краснодар (861)203-40-90	Оренбург (3532)37-68-04	Томск (3822)98-41-53
Волгоград (844)278-03-48	Красноярск (391)204-63-61	Пенза (8412)22-31-16	Тула (4872)74-02-29
Вологда (8172)26-41-59	Курск (4712)77-13-04	Пермь (342)205-81-47	Тюмень (3452)66-21-18
Воронеж (473)204-51-73	Липецк (4742)52-20-81	Ростов-на-Дону (863)308-18-15	Ульяновск (8422)24-23-59
Екатеринбург (343)384-55-89	Магнитогорск (3519)55-03-13	Рязань (4912)46-61-64	Уфа (347)229-48-12
Иваново (4932)77-34-06	Москва (495)268-04-70	Самара (846)206-03-16	Челябинск (351)202-03-61
Ижевск (3412)26-03-58	Мурманск (8152)59-64-93	Санкт-Петербург (812)309-46-40	Череповец (8202)49-02-64
Казань (843)206-01-48	Набережные Челны(8552)205341	Саратов (845)249-38-78	Ярославль (4852)69-52-93

Единый адрес для всех регионов mtt@nt-rt.ru || <http://mttd.nt-rt.ru>